

# Future Technology Devices International Ltd. Application Note AN\_103 FTDI Drivers Installation guide for Windows VISTA

Document Reference No.: FT\_000080 Version 1.0 Issue Date: 2008-09-23

The purpose of this document is to provide users of FTDI chips with a simple procedure for installing FTDI drivers for their devices under Windows VISTA.

Future Technology Devices International Limited (FTDI)

373 Scotland Street, Glasgow G5 8QB United Kingdom Tel.: +44 (0) 141 429 2777 Fax: + 44 (0) 141 429 2758 E-Mail (Support): support1@ftdichip.com Web: http://www.ftdichip.com

Copyright © 2008 Future Technology Devices International Limited



## **Table of Contents**

1	In	troduction2
2	In	stalling FTDI Device Drivers3
3	In	stalling CDM Drivers4
4	Un	installing FTDI Devices16
5	Tre	oubleshooting17
Į	5.1	Windows VISTA cannot find drivers for my device
Į	5.2	Devices not shown in Device Manager for uninstalling
Į	5.3	Windows Vista shows a warning that the driver is not certified 19
Į	5.4	Driver will not install on VISTA x64
6	Со	ntact Information21
Aŗ	ope	ndix A – Revision History22



## **1** Introduction

The purpose of this application note is to provide users of FTDI chips with a simple procedure for installing FTDI drivers for their devices under Windows VISTA.



## 2 Installing FTDI Device Drivers

FTDI have previously provided two types of driver for Windows OS: a D2XX direct driver and a virtual COM port (VCP) driver. Previously, these drivers were mutually exclusive and could not be installed at the same time. The new Windows combined driver model (CDM) which may be installed on Windows 2000, XP or VISTA allows applications to access FTDI devices through either the D2XX DLL or a COM port without having to change driver type. However, it should be noted that an application can only communicate through one of these interfaces at a time and cannot send commands to the D2XX DLL and the associated COM port at the same time.

The CDM driver comes in two parts. The first part is the bus layer that provides D2XX style functionality and is always installed. The second part is the serial COM port layer and the CDM driver will determine whether a COM port should be exposed by reading the EEPROM of FT232R, FT245R and FT2232D devices. In the case of FT232BM, FT245BM, devices, the CDM driver will default to always installing a COM port.

This behaviour can be changed and EEPROM settings ignored by changing the driver INF files as detailed in FTDI Application Note AN232B-10 Advanced Driver Options. Please note that modifying the INF files of a Microsoft WHQL certified driver will invalidate the Windows certification.

The driver is downloadable from the FTDI website by clicking the word download: download.



## 3 Installing CDM Drivers

To install CDM drivers for an FTDI device under Windows VISTA, follow the instructions below:

Connect the device to a spare USB port on your PC.

If there is an available Internet connection, Windows VISTA will silently connect to the Windows Update website and install any suitable driver it finds for the device in preference to the driver manually selected. If no suitable driver is automatically found then the following procedure should be followed.

If the device is based on the FT2232D, the Microsoft composite device driver is automatically loaded silently in the background. Once the composite driver has been installed Windows Found New Hardware Wizard will launch. If there is no available Internet connection or Windows VISTA is configured to ask before connecting to Windows Update, the screen below is shown. Select "Locate and install driver software (recommended)" from the options available to proceed with the installation.

Found New Hardware	X
Windows needs to install driver software for your TTL23 Tester	2R
Locate and install driver software (recommended) Windows will guide you through the process of installing driver soft for your device.	ware
Ask me again later Windows will ask again the next time you plug in your device or log	J on.
Don't show this message again for this device Your device will not function until you install driver software.	
Car	ncel



When Locate and install driver software (recommended)" is selected the following screen will appear. Note: the text "TTL Tester" is replaced with the description of the customer hardware.

0	Found New Hardware - TTL232R Tester	
	Insert the disc that came with your TTL232R Tester If you have the disc that came with your device, insert it now. Windows will automatically search the disc for driver software.	
	✤ I don't have the disc. Show me other options.	
		Cancel

Select "I don't have the disk. Show me other options" The next screen will appear.



		X
9	Found New Hardware - TTL232R Tester	
Wir	ndows couldn't find driver software for your device	
*	Check for a solution Windows will check to see if there are steps you can take to get your device working.	
÷	Browse my computer for driver software (advanced) Locate and install driver software manually.	
		Cancel

Select "Browse my computer for driver software (advanced)". The next screen will appear.



Found New Hardware - TTL232R Tester	E
Found New Hardware - TTL232K Tester	
Browse for driver software on your computer	
Search for driver software in this location:	
C:\Users\\Desktop\CDM 2.00.00 (Certified)	Browse
Include subfolders	
	Next Cancel

Browse to the folder where the CDM driver has been stored (when uncompressed) and press "Next" The example shown above uses a folder on the desktop. The next screen will appear.



Sound New Hardware - TTL232R Tester	
Installing driver software	




This screen will automatically complete and then change to the one below:

G I Found New Hardware - USB Serial Converter	×
The software for this device has been successfully installed	
Windows has finished installing the driver software for this device:	
USB Serial Converter	
	ose

The bus layer of the driver is now installed.

When the bus driver has completed, the process is repeated for the serial port layer of the driver. That is, Windows will automatically detect a serial port device as a new device. It will then prompt, as before, for the location of the device driver by displaying the "Found new hardware" wizard again and it is necessary to repeat the same process to install the serial port driver.





Select "I don't have the disk. Show me other options" The next screen will appear.



	8
G Eound New Hardware - USB Serial Port	
Windows couldn't find driver software for your device	
Check for a solution Windows will check to see if there are steps you can take to get your device working.	
Browse my computer for driver software (advanced) Locate and install driver software manually.	
	Cancel

Select "Browse my computer for driver software (advanced)". The next screen will appear.



🕘 🧕 Found New	Hardware - USB Serial Port	
Browse for	driver software on your computer	
Search for drive	r software in this location:	
C:\Users	\Desktop\CDM 2.00.00 (Certified)	Browse
Include subf	olders	
		Next Cancel

Browse to the folder where the CDM driver has been stored (when uncompressed) and press "Next" The example shown above uses a folder on the desktop.

The next screen will appear.



	×
🥪 🚊 Found New Hardware - USB Serial Port	
Installing driver software	
	- 1



This screen will automatically complete and then the following screen will appear.

G I Found New Hardware - USB Serial Port (COM3)	8
The software for this device has been successfully installed	
Windows has finished installing the driver software for this device:	
USB Serial Port	
	Close

If the device is based on the FT2232D, the second port must also be installed. The procedure for installing the second port is identical to that for installing the first port from the first screen of the Found New Hardware Wizard for the USB Serial Port device. If the driver is Microsoft WHQL certified, this is done automatically.

After the driver is installed it is important to determine which COM port has been assigned to the device for configuring the application that will use the device.

Open the Device Manager (located in "Control Panel\System" then select the "Hardware" tab and click "Device Manager") and select "View > Devices by Connection", the device appears as a" USB Serial Converter" with an additional COM port with the label "USB Serial Port". If the device is based on the FT2232D, two ports will be available from a composite USB device.



Device Manager	
ile Action View Help	
🕀 📭 Computer	
🕀 👝 Disk drives	
🗄 📲 Display adapters	
B DVD/CD-ROM drives	
🗈 🛁 Floppy disk drives	
🕀 🚽 Floppy drive controllers	
🗄 🕼 Human Interface Devices	
IDE ATA/ATAPI controllers	
🕢 🟺 IEEE 1394 Bus host controllers	
🕀 🛲 Keyboards	
Mice and other pointing devices	
🕣 💵 Monitors	
🗈 💇 Network adapters	
🕀 🔟 Portable Devices	
🖶 🖤 Ports (COM & LPT)	
- 🖓 Communications Port (COM1)	
Printer Port (LPT1)	
USB Serial Port (COM3)	
Processors	
🖕 🛋 Sound, video and game controllers	
🔤 🛶 High Definition Audio Device	
🕀 🗢 Storage controllers	
🛓 🚛 System devices	
🗄 🖷 🖟 Universal Serial Bus controllers	

This screen shows the device connected to COM3.

In the case of the FT2232D, port A of the FT2232D will be installed as COMX and port B will be installed as COMX+1 where COMX is the first available COM port number.



#### 4 Uninstalling FTDI Devices

With the release of Microsoft Windows Vista, the FTDI uninstaller has been rendered unusable due to Windows Resource Protection preventing the executable from deleting driver files and associated registry values. Vista will only allow the system itself to modify files and registry values in these locations.

Consequently, a new method for uninstalling is required. Devices can be removed using the Device Manager by simply right-clicking on the mouse and selecting "Uninstall". This will delete the associated registry entries for that device only. Vista provides an automatic method to delete driver files via a check box to "Delete the driver software for this device" on the uninstall dialog box.

Confirm Device Uninstall	
USB Serial Converter	
Warning: You are about to uninstall this device from your system.	
Delete the driver software for this device.	
OK Cancel	

Windows 2000, XP and Server 2003 do not have this check box, so driver files and OEM INF and PNF files must be removed manually or by using a custom application.

Some points to note about the new un-installation method:

- In the case of FT2232 devices, a composite device is also installed. This can also be removed by right-clicking and selecting "Uninstall". There is no option to delete the driver files when doing this as the driver for the composite device is a native Windows driver.
- If the VCP driver has been installed, the COM port driver should be uninstalled before the bus driver. If the bus is removed first, the COM port will no longer appear in the Device Manager.
- If the files are deleted while other installed devices still require them those devices will not work correctly. This can be fixed by right clicking the device and selecting "Reinstall Driver" which will replace the missing files.
- If a device to be uninstalled is not connected to the PC, the device can still be removed by setting the device manager to show phantom devices. This also allows a virtual COM port to be uninstalled if the bus layer has been removed first.



#### 5 Troubleshooting

#### 5.1 Windows VISTA cannot find drivers for my device

This error can occur if the VID and PID programmed into the device EEPROM do not match those listed in the INF files for the driver. The VID and PID programmed into the device EEPROM may be found by using the USBView utility from the FTDI web site. These can then be checked against the VID and PID entries in the driver INF files. If they do not match, that driver cannot be installed for that device without either re-programming the device EEPROM or modifying the list of VID and PID numbers in the INF files. Please note that only your own company VID and PID or FTDI's VID (0x0403) and FTDI PID issued for use by the customer should be used in the EEPROM and INF files.

End customers should obtain modified drivers from the OEM of the device, and not necessarily edit the files themselves.



#### 5.2 Devices not shown in Device Manager for uninstalling

Devices that have been installed on a system but are not currently available are referred to as "phantom devices". These devices are not usually displayed in the device manager, but can be made to be displayed as though they are attached. This allows device properties to be changed or devices to be uninstalled via Device Manger even though the device is not physically connected to the PC.

To display phantom devices in Device Manager, a new system variable is required. Open "Control Panel > System" then select the "Advanced" tab and click "Environment Variables". In the System Variables section (**NOT THE USER VARIABLES SECTION**), click "New..." to display the following window:

Edit System Variable	
Variable <u>n</u> ame:	DevMgr_Show_NonPresent_Devices
Variable <u>v</u> alue:	1
	OK Cancel

Create a new System Variable called "DevMgr\_Show\_NonPresent\_Devices" and set the value to 1, then click OK.

Open the Device Manager ("Control Panel > System" then select the "Hardware" tab and click "Device Manager...", or "Control Panel > Device Manger" in Vista) and select "View > Show Hidden Devices". Device Manager will then show all hidden and phantom devices available on that PC as shaded.



#### 5.3 Windows Vista shows a warning that the driver is not certified

If the driver is not certified then a pop up window such as shown below will be displayed.



If you are certain of the source of the driver the warning can be ignored and you can continue installation by selecting "Install this driver software anyway".

If you are unsure about the driver source contact your vendor.



#### 5.4 Driver will not install on VISTA x64

VISTA x64 OS will only allow certified drivers to be installed. The certified driver supplied by FTDI will work with VID 0403 and PID 6001 for FT232 and FT245 devices. It will also work with VID 0403 and PID 6010 for FT2232 devices.

If you have a product where the manufacture has customised the driver but has not re-certified it, then the driver will not load. You should contact your vendor to determine if they will support VISTA x64.



#### **6** Contact Information

#### Head Office – Glasgow, UK

Future Technology Devices International Limited 373 Scotland Street Glasgow G5 8QB United Kingdom Tel: +44 (0) 141 429 2777 Fax: +44 (0) 141 429 2758

E-mail (Sales) vinculum.sales@ftdichip.com E-mail (Support) vinculum.support@ftdichip.com E-mail (General Enquiries) admin1@ftdichip.com Web Site URL http://www.ftdichip.com Web Shop URL http://www.dftdichip.com

#### Branch Office – Taipei, Taiwan

Future Technology Devices International Limited (Taiwan) 4F, No 18-3, Sec. 6 Mincyuan East Road Neihu District Taipei 114 Taiwan, R.O.C. Tel: +886 (0) 2 8791 3570 Fax: +886 (0) 2 8791 3576

E-mail (Sales) tw.sales1@ftdichip.com E-mail (Support) tw.support1@ftdichip.com E-mail (General Enquiries) tw.admin1@ftdichip.com Web Site URL http://www.ftdichip.com

#### Branch Office – Hillsboro, Oregon, USA

Future Technology Devices International Limited (USA) 7235 NW Evergreen Parkway, Suite 600 Hillsboro, OR 97123-5803 USA Tel: +1 (503) 547 0988 Fax: +1 (503) 547 0987

E-Mail (Sales) us.sales@ftdichip.com E-Mail (Support) us.admin@ftdichip.com Web Site URL http://www.ftdichip.com

#### **Distributor and Sales Representatives**

Please visit the Sales Network page of the FTDI Web site for the contact details of our distributor(s) and sales representative(s) in your country.

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. Future Technology Devices International Ltd will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Future Technology Devices International Ltd, 373 Scotland Street, Glasgow G5 8QB United Kingdom.



## Appendix A – Revision History

Version 0.1First DraftVersion 1.0First Release

21/08/2008 23/09/2008